

Jig Credenza



- _Door finishes: natural oak, black oak and white
- _Cabinet and base finishes, natural oak and black oak
- _Stitched handles in fabric, vinyl or leather
- _Low, high and low/high configurations
- _Upholstered seat panel option
- _Upholstered back panel option

Door Finishes



Cabinet/Base Finishes



Fabric back option



Fabric seat pad option



Fabrics

See page 284



_Fabric handle option




_Low/high with upholstered seat pad

Jig Credenza




How to specify



Step 1


Select Base Finish:
Natural Oak or Black Oak

Choose Cabinet Combination:
Low/Low, High/Low, Low/High or High/High




Step 2

Select Cabinet Finish:
Natural Oak or Black Oak



Step 3

Select Door Finish:
Natural Oak, Black Oak or White



Step 4

Select Handle Style:
Upholstered or Push-to-open (handleless)

Choose Seat Pad (if required):
Full length or half length

Choose Upholstered Back Panel:
(charged as an optional extra)



Jig Credenza Low/Low

height 63, width 184, depth 47 (cm)

Base finish - Natural Oak or Black Oak
Cabinet finish - Natural Oak or Black Oak
Door finish - Natural Oak, Black Oak or White

Description	Order Code
Fabric Handle	JZLL/F
Push to Open (Handle-less)	JZLL/P



Jig Credenza High/Low & Low/High

height 63/73, width 184, depth 47 (cm)

Base finish - Natural Oak or Black Oak
Cabinet finish - Natural Oak or Black Oak
Door finish - Natural Oak, Black Oak or White

Description	Order Code
High/Low	
Fabric Handle	JZHL/F
Push to Open (Handle-less)	JZHL/P
Low/High	
Fabric Handle	JZLH/F
Push to Open (Handle-less)	JZLH/P



Jig Credenza High/High

height 73, width 184, depth 47 (cm)

Base finish - Natural Oak or Black Oak
Cabinet finish - Natural Oak or Black Oak
Door finish - Natural Oak, Black Oak or White

Description	Order Code
Fabric Handle	JZHH/F
Push to Open (Handle-less)	JZHH/P



Jig Credenza Upholstered Back Panels

Low Back Panel / High Back Panel

Fabric Band	Order Code Low Back Panel	Order Code High Back Panel
A	JZBPSL/FA	JZBPSH/FA
B	JZBPSL/FB	JZBPSH/FB
C	JZBPSL/FC	JZBPSH/FC
D	JZBPSL/FD	JZBPSH/FD
E	JZBPSL/FE	JZBPSH/FE
F	JZBPSL/FF	JZBPSH/FF
G	JZBPSL/FG	JZBPSH/FG
H	JZBPSL/FH	JZBPSH/FH
I	JZBPSL/FI	JZBPSH/FI

Two pieces have to be specified. Each unit is made up of two cabinets, for example: Low + Low, High + Low.



Jig Credenza Seat Pads

Half Seat Pad / Full Length Seat Pad

Fabric Band	Order Code Half Seat Pad	Order Code Full Length Seat Pad
A	JZSS/FA	JZDS/FA
B	JZSS/FB	JZDS/FB
C	JZSS/FC	JZDS/FC
D	JZSS/FD	JZDS/FD
E	JZSS/FE	JZDS/FE
F	JZSS/FF	JZDS/FF
G	JZSS/FG	JZDS/FG
H	JZSS/FH	JZDS/FH
I	JZSS/FI	JZDS/FI